
1BB01
Power Distribution Box
MAIN_SUPPLY
F19
F20
C662-1
F19_60A
C663-1
F20_60A
SDC02A 14K733 3TBD 25.0 RD MAIN
C1BB01-B-1
C3-1
C1BB03-J-1
C1BB03-K-1
SBB19C 14K733 2TBD 6.0 BU-RD MAIN
SBB20G 14K733 2TBD 6.0 GN-RD EJB_HIGH
C12-CD-2
C12-CD-1
GD108A 14301 3TBD 35.0 BK EN_0D
G1D108-A
1D108
BODY BATTERY GROUND
C1D02-A-1
G1D134-B-1
FUSE
1DC02
(+)
(-)
BATTERY
SBB20L 14014 2TBD 6.0 GN-RD RJB_3
SBB19D 14014 2TBD 6.0 BU-RD MAIN
4BR02
Rear Junction Box (RJB)
C4BR02-A-129
C1-129
FA8
FA8/20A
C1-118
C4BR02-A-118
A_SBR08A 14014 2TBD 1.5 VT-RD SCU
C4PK28-D-2
C4BR02-C-330
C3-330
FC5
FC5/20A
C3-323
C4BR02-C-323
C_SBR05A 14014 2TBD 1.5 GY-RD SCU
C4PK28-D-1
4PK28
Keyless Vehicle Module
CAN
P-RANGE SW/ CLUTCH 75% SW C5-17
C2Pk28-A=C1
C2PK28-B=C2
C2PK28-C=C3
C2PK28-D=C4
C2PK28-E=C5
VBAT POWER ESCL C4-2
VBATT POWER KVM C4-1
SP549
GD150AF 14014 2TBD 2.5 BK-WH CD340
GD150AH 14014 2TBD 4.0 BK-WH BS_08
GD150K 14014 2TBD 1.5 BK-WH 4DOOR
C44-MN-14
C44-KL-2
C44-MN-4
GD150RA 17N400 2TBD 1.5 BK-WH CD340
GD150RB 17N400 2TBD 1.5 BK-WH BS_08
GD150R 17N400 2TBD 1.5 BK-WH 4DOOR
SP534
GD150AA 17N400 2TBD 0.75 BK CAQAB
C4PL45-A-2
4PL45
Liftgate/Luggage Compartment Lid Release Switch
C1-2
C1-1
CPL45B 17N400 2TBD 0.75 BK CAQAB
C4PL45-A-1
GD150D 14014 2TBD 6.0 BK-WH MAIN
G4D149
4D149
REAR LEFT SUPPORT POWER GROUND
SJB 6A
CPL45A 14014 2UAY 0.13 BN MAIN
C44-MN-1
CPL45C 14014 2UAY 0.13 BN KV
C4PK28-E-9
TAILGATE RELEASE SW C5-9
SJB 6A
A_CLN17G 14014 2TBD 0.50 BN RSE_KV
SP564
A_CLN17XA 14014 2TBD 0.50 BN KV_RHD
C26-AXB-20
A_CLN17W 14A584 2TBD 0.50 BN KV
SP492
5PK29
Central Locking Lock/Unlock Switch
C5PK29-1
C5PK29-2
C5PK29-4
C1-1
C1-2
C1-4
SP702
GD150CT 14A584 2TBD 0.35 BK-WH KV
BK-VT
2TBD 2.5 MAIN
2TBD 0.75 BK-VT KV
GD134F 14014
GD134E 14014
BK-WH
2TBD 0.35 KV
SP386
BK-VT
2TBD 1.0 MAIN
GD134M 14014
C25-AXB-16
GD150CK 14A584
BN-GN
2TBD 0.35 KV
RPL61B 14A584
C26-AB-10
RPL61AA 14014 2TBD 0.35 BN-GN KV_RHD
C4PK28-E-10
CENTRAL UNLOCK SW C5-10
G3D133
3D133
LEFT A-POST POWER GROUND
4PK31
Liftgate/Luggage Compartment Lid Lock Switch
C4PK31-2
C4PK31-1
GD150CR 17N400 2TBD 0.50 BK-WH KV
CPL22A 17N400 2TBD 0.35 GN-VT KV
C44-MN-16
CPL22B 14014 2UAY 0.13 GN-VT KV
C4PK28-E-19
LOCK SW TRUNK C5-19
4PK07
Keyless Vehicle Rear Bumper Antenna
C4PK07-2
C4PK07-1
RPK07A 14014 2TBD 0.35 GN-OG KV
VPK07A 14014 2TBD 0.35 VT KV
C4PK28-A-7
C4PK28-A-16
EXTERIOR BUMPER ANTENNA - C1-7
EXTERIOR BUMPER ANTENNA + C1-16
GD135G 14014 2TBD 1.0 BK-GY MAIN
GD135C 14014 2TBD 0.50 BK-GY SCU
SP388
SP389
GD135A 14014 2TBD 0.50 BK-GY SCU
GD135B 14014 2TBD 0.50 BK-GY SCU
C4PK28-C-4
C4PK28-D-3
GND SIGNAL 1 C3-4
GND SIGNAL 2 C4-3
G3D135
3D135
DRIVER A-POST 3 SIGNAL GROUND
UNLOCK PULL SW FONT RIGHT C5-7
LOCK SW FRONT RIGHT C5-11
EXTERIOR ANTENNA RIGHT + C1-10
EXTERIOR ANTENNA RIGHT - C1-3
LATCH CLUTCH SW FRONT RIGHT C2-17
LATCH RELEASE FRONT RIGHT - C2-2
LATCH RELEASE FRONT RIGHT + C2-7
UNLOCK PULL SW REAR RIGHT C5-5
LATCH CLUTCH SW REAR RIGHT C2-15
LATCH RELEASE REAR RIGHT - C2-4
LATCH RELEASE REAR RIGHT + C3-1
UNLOCK PULL SW FRONT LEFT C5-6
LOCK SW FRONT LEFT C5-12
EXTERIOR ANTENNA LEFT + C1-8
EXTERIOR ANTENNA LEFT - C1-1
LATCH CLUTCH SW FRONT LEFT C2-16
LATCH RELEASE FRONT LEFT - C2-1
LATCH RELEASE FRONT LEFT + C2-5
UNLOCK PULL SW REAR LEFT C5-4
LATCH CLUTCH SW REAR LEFT C2-14
LATCH RELEASE REAR LEFT - C2-3
LATCH RELEASE REAR LEFT + C3-2
KV-START
INTERIOR ANTENNA REAR + C1-11
INTERIOR ANTENNA REAR - C1-12
INTERIOR ANTENNA REAR - C1-4
INTERIOR ANTENNA FRONT - C1-9A
INTERIOR ANTENNA FRONT + C1-2A
INTERIOR ANTENNA FRONT + C1-2
INTERIOR ANTENNA FRONT - C1-9
INTERIOR ANTENNA CENTRE + C1-17
INTERIOR ANTENNA CENTRE - C1-5
GND POWER C3-3


6PK24
Front Door Unlock Switch RH
6PK20
Front Door Lock Switch RH
6PK10
Front Door Latch Release Motor RH
8PK26
Rear Door Unlock Switch RH
8PK12
Rear Door Latch Release Motor RH
5PK23
Front Door Unlock Switch LH
5PK19
Front Door Lock Switch LH
5PK09
Front Door Latch Release Motor LH
7PK25
Rear Door Unlock Switch LH
7PK11
Rear Door Latch Release Motor LH
4PK08
Keyless Vehicle Rear Antenna
1PK05
Keyless Vehicle Front Antenna
1PK05
Keyless Vehicle Front Antenna
3PK06
Keyless Vehicle Center Antenna
RIGHT A-POST POWER GROUND
LEFT A-POST POWER GROUND
REAR RIGHT SUPPORT POWER GROUND
SP491
SP704
SP392
SP703
SP492
SP386
SP702
SP701
G3D138
3D138
G3D133
3D133
G4D151
4D151